ADVENT®



UBTSW1

Owner's Manual

Bluetooth Hands Free Vehicle Kit

IMPORTANT NOTE: The operation of the Bluetooth Hands Free Kit as described in this manual is applicable to most phones. However, due to the configuration of some phones, some functions may not apply. Please see your installing dealer for more information.

Downloaded from www.Manualslib.com manuals search engine

Using Your Bluetooth Hands Free Kit

Powering On/Off

The bluetooth kit will automatically turn on when the vehicle's key is turned to the accessory position and will remain on until the vehicle's accessory power is turned off. After turning on, the bluetooth kit will automatically search for phones that have been paired with it. Since it is possible to have multiple phones paired to the system the order of priority of connecting will be the latest phone paired, the phone most used with the system, the phone second most used phone with the system. If the bluetooth kit has not been paired to a phone pairing will automatically activate.

Making a Call

When connected to the bluetooth kit you may use your phone as normal to dial numbers or search your contacts list or by using Voice Dialing.

Voice Dialing

To activate voice dialing press the ANSWER/END key on the bluetooth keypad, the system will prompt you for a command. Clearly speak your command (example, "Call Shaun"). The system will then confirm the command and in this example will then call "Shaun".

Ending a Call

To end a call press the ANSWER/END key.

Answer a Call

When there is an incoming call the vehicle's radio will be muted/turned off and the call will ring through the vehicle's speaker, to answer press the ANSWER/END key.

Ignore an Incoming Call

To Ignore an incoming call press and hold the ANSWER/END key for 2 to 5 seconds.

Redial the Last Number

To redial the last number press and hold the ANSWER/END key for 2 seconds.

Adjusting the Call Volume

While in a call, to adjust the volume up/down with the ANSWER/END key, pressing and holding the ANSWER/END key will automatically raise or lower the volume. When the max volume is reached it is set up to automatically lower the volume down to the min level. The system will beep 2 times when the min/max volume levels are reached.

Transfer a Call

To transfer a call between bluetooth hands free or normal phone operation press and hold the ANSWER/END key on the bluetooth keypad for 2 seconds.

Pairing

To activate phone pairing press and hold the ANSWER/END key for 10 seconds, the system will beep 3 times. At this time you will need to activate pairing on the phone, see your phones owners manual. The PIN code for pairing is 1234 and will need to be entered into your phone at the time of pairing.

*Throughout this manual, 'press' refers to pressing for less than 1 second, 'press and hold' refers to pressing for 2 seconds.

Downloaded from www.Manualslib.com manuals search engine

Using Your Bluetooth Hands Free Kit, continued

Manual Search for Paired Phone

If your phone is not connected to or has been disconnected by you from the bluetooth kit but has previously been paired to the system you can activate the manual search which will locate your phone and connect to it. To activate a manual search press the ANSWER/END key.

Manual Temporary Disconnect

To temporarily disconnect the currently connected phone from the bluetooth kit press and hold the ANSWER/ END key for 5 seconds, the system will beep 2 times.

Reset / Clear All Paired Phones

To permanently remove all paired phones from the bluetooth kit press and hold the ANSWER / END key for 15 seconds, the system will beep 4 times.

Quick Reference

Quick Reference Guide - 1 Button Switch

FUNCTION	KEYPAD BUTTON	NOTES
Power Unit Up	-	Turn vehicle accessory ON
Make A Call	-	Use phone as normal
Answer Call	ANSWER/END	Press and release
End Call	ANSWER/END	Press and release
Voice Dialing	ANSWER/END	Press and release
Redial Last Number	ANSWER/END	Press and hold for 2 seconds
Transfer Call	ANSWER/END	Press and hold for 2 seconds
Ignore Call	ANSWER/END	Press and hold 2 - 5 seconds
Volume	ANSWER/END	Press and hold
Mute	ANSWER/END	N/A
Pairing	ANSWER/END	Press and hold 10 seconds
Manual Search	ANSWER/END	Press and release
Reset	ANSWER/END	Press together for 15 seconds
Disconnect Bluetooth	ANSWER/END	Press and hold for 5 seconds



Downloaded from www.Manualslib.com manuals search engine

4 This page intentionally left blank.

Downloaded from www.Manualslib.com manuals search engine

This page intentionally left blank.

Downloaded from www.Manualslib.com manuals search engine

This page intentionally left blank.

Downloaded from www.Manualslib.com manuals search engine

ADVENT®

36 MONTH LIMITED WARRANTY

Applies to Bluetooth Automotive/Cellular Interface Products.

AUDIOVOX Electronics Corp. (the Company) warrants to the original retail purchaser of this product that, should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 36 months from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the Company's option) without charge for parts.

Simply call toll free to our control office for reference to the authorized Warranty Station in your area and to obtain an Authorization number. No repairs or replacement will be made without a valid Authorization number.

TRAVELER'S WARRANTY SERVICE 1-800-645-4994

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), authorization number, specification of defect(s), transportation prepaid, to an approved warranty station. This warranty is not transferable.

This Warranty does not cover damage to vehicle electrical system. This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s).

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 48 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

The Company does not warrant that this product cannot be compromised or circumvented. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE PURCHASER FOR THE PRODUCT.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

128-8437

- **TRAVELER'S WARRANTY DEPARTMENT**
- **AUDIOVOX ELECTRONICS CORPORATION**
- **150 MARCUS BLVD HAUPPAUGE, NEW YORK 11788**

Downloaded from www.Manualslib.com manuals search engine

FCC COMPLIANCE

This device complies with Part 15 of the FCC rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including any interference that may cause undesired operation.

Warning!

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Downloaded from www.Manualslib.com manuals search engine